

## Instructions for cutting the screws fastening the cylinder lock

- Before installing the screw should be cut to a length of 35 mm. MAX 42mm
- Install the cylinder in the lock housing with the fastening screw.

**ATTENTION!** Too long fastening screw may result in the destruction of the glazing set.

- The screw must be tightened by the hand with a screwdriver (cross type).
- The manufacturer is not responsible for damage to the glazing set.

